

# SunStat Non-programmable Thermostat Model 500675

## Owner's Manual

Your new SunStat Nonprogrammable thermostat is designed to control the voltage to either a 120VAC or 240VAC resistive floor warming system.

Please follow this manual for complete installation and operation instructions. If you have any questions or comments, try calling Technical Support at 1-800-276-2419.

**CAUTION:** Make sure you are qualified and are familiar with house wiring. This is a line voltage device that could cause serious injury or damage if improperly installed.

### 1. Preparation

1. Unpack your thermostat and make sure everything is in good condition:

- Thermostat
- Floor sensor
- Small screwdriver
- Mounting screws
- Wire nuts for wiring connections

If any parts are missing or damaged, contact the store where you purchased this thermostat. Do not install a damaged part.

2. Gather the following tools and supplies:

- Phillips screwdriver, hole saw
- Wire strippers, "fish tape", other electrical tools
- Electrical box for thermostat:
  - a. If you are connecting to power leads from only 1 or 2 floor warming systems, you may use a single-gang, 3½ inch deep box.
  - b. If you are connecting to power leads from 3 floor warming systems, use a 4x4x2½ inch or deeper box (not a 2-gang box) when your wall studs are still exposed. Install a single-gang "mud-ring" cover on the box before installing drywall materials.
  - c. For more than 3 floor warming systems or other layouts, you may need to install a junction box to connect the power leads together. Then use house wire to connect between the junction box and the thermostat electrical box. See the installation instructions for your floor warming system for more information.

**ALWAYS:** Wire all circuits as Class 1, Electric Light and Power Circuits.

**ALWAYS:** Wire all circuits with insulation rated 600V minimum.

**ALWAYS:** Mount this control only to a grounded metallic box or a nonmetallic box.

**ALWAYS:** Use power supply wires suitable for at least 90°C.

**CAUTION:** High voltage - disconnect power supply before servicing.

**CAUTION:** The GFCI in this control does not protect against shock if both bare conductors are touched at the same time.

### 2. Installation

#### Remove the Thermostat Face

1. Remove the thermostat Front Module from the Power Module by opening the door and loosening the screw.

2. Pull outward near the bottom on the Front Module and lift off. Be careful not to bend or damage the 14-pin electrical connector on the back of the Front Module.

#### Prepare the Wiring

1. Find a location for your thermostat. It is suitable for indoor use only, on insulated or uninsulated walls. Locate it about 4½ feet to 5 feet above the floor on an inside wall. Make sure it is well ventilated and not located in a confined space such as a small closet or cabinet. Avoid placing it near other heat sources such as hot-water piping, heat duct, wall-mount lighting, and direct sunlight to help prevent adversely affecting the thermostat.

2. Turn off the power to the floor warming system at the main circuit panel before doing any electrical work.

3. A qualified electrician should run a dedicated circuit from the main circuit panel to the thermostat location.

4. If a dedicated circuit is not possible, you may tap from another circuit in the room. Make sure there is enough load capacity (amps) to handle the addition

of your floor warming system, and that it is NOT wired in series with any other device, including other GFCIs.

5. The circuit breaker in the main circuit panel should be 15 amps maximum for a floor warming system totaling 12 amps or less. For larger systems up to 15 amps, use a 20 amp maximum circuit breaker. Never exceed 15 amps on this thermostat. You may consider using an arc-fault (AFCI) type circuit breaker for additional protection.

6. Pull the power supply wiring into this box, leaving about 6 inches of wire.

7. Pull the floor sensor wire and the power lead wires from your floor warming system up the wall, into this box. Refer to your floor warming system installation instructions for placement of the floor sensor tip into the floor area.

**Note:** The sensor wires should not be run in the same conduit as line voltage wires to avoid possible interference. If the sensor lead wires are not long enough, they may be extended an additional 15 feet (4.5 m) using minimum 20-gage 2-conductor wire or up to 50 feet (15 m) using shielded wire.

8. Mount the electrical box.

#### Connect Wires

1. Match and connect the two wires marked "LINE1" and "LINE2" to the power supply wires using the wire nuts provided.

2. Gently tug on the wires to make sure they are secure, otherwise a wire could loosen and cause failure.

3. Overwrap the wire nuts with electrical tape to better secure them to the wires.

4. Match and connect the two wires marked "LOAD1" and "LOAD2" to the floor warming system lead wires and secure these wires the same way.

5. Connect the house ground wire to the green or bare lead wire(s) of your floor warming system.

6. Insert the ends of the floor sensor wire into the "SENSOR" terminals (1 and 2) and tighten the screws. There is no polarity, so it does not matter which wire end goes into which terminal.

**CAUTION:** Before continuing, make sure your power supply voltage matches the voltage rating of your floor warming system.

**Connecting 240V to a 120V floor warming system will cause overheating and damage to the system and may damage the control, other wiring, floor coverings, etc.**

#### Remote Control

1. If you want to connect your thermostat to a remote control device, such as a home automation system, first make sure that the remote device has a "dry contact" output (an un-energized switch, such as the contacts on a relay). Many home automation systems come with such an output that opens or closes at specified times.

2. Pull 2-conductor wire, size 18- to 24-gage, through the wall from the remote device, into this electrical box.

3. Connect the wire ends into the "SETBACK" terminals (5 and 6) and tighten the screws (no polarity).

#### SunStat Relays

1. If you want to use your thermostat to drive a SunStat Relay(s) (ask your dealer about this convenient way to control larger systems with one thermostat), first read and follow the instructions for the SunStat Relay thoroughly.




2. Pull 2-conductor wire, size 18- to 24-gage, through the wall from the SunStat Relay, into this electrical box. This wire may be up to 100 feet (30 m) in length from the thermostat to the last SunStat Relay installed.

3. Connect the wire ends into the "RELOUT" terminals (3 and 4) and tighten the screws (Observe polarity of the wires when connecting to the SunStat Relay).

#### Mount the Thermostat

1. Carefully fold and press the wires back into the electrical box. Do not use the thermostat to push them in, as this may cause connections to loosen and possible failure.

2. Secure the thermostat Power Module



into the box with the mounting screws provided.

3. Carefully snap the Front Module onto the Power Module. Be careful not to bend or damage the 14-pin electrical connector on the back of the Front Module.

4. Tighten the screw.

5. Switch on the power at the main circuit panel.

**NOTE to contractors:** After installing the thermostat, be sure to:

- Do a Quick Setup (section 3),
- Temporarily override the setpoint temperature to make sure it is heating for a few minutes (section 5),
- Test the GFCI (section 5).

## 3. Quick Setup

### On/Off Switch

Your thermostat should be turned off when it is first installed. The display will show **OFF**.

1. Slide the on/off switch to the upper position, turning the thermostat on. The display will show the sensor temperature, setpoint temperature, and other information.

2. To turn the thermostat off anytime, slide the on/off switch to the lower position. No heating will occur and all settings are retained.



### Change Format Between °F (Fahrenheit) and °C (Celsius)

Your thermostat is factory set to operate in either °F format or °C format. If needed, you may change this at any time as follows:

- Press the OPTIONS button and hold for 1 second. An °F will show on the display.
- Press the down or up button to toggle °C.
- Press the HOLD/RETURN button to return to the normal operating mode.

°F

## 4. Additional Setups

### Air Sensing and Regulator Modes

Your thermostat is factory set to operate based on the floor sensor temperature. This is the recommended method to properly control your floor warming system.

However, it is also possible to operate your thermostat in either the air sensing mode or regulator mode temporarily if the floor sensor was damaged or not installed. A new floor sensor should be installed to enable operation in Floor Sense Mode as soon as possible. These modes must be used with caution to avoid overheating the floor.

- Air Sensing Mode** – This operates by an air sensor inside the thermostat. You must set a Floor Limit temperature to avoid overheating the floor coverings (see **Floor Limit** below). **Note:** the internal heating in the thermostat may affect the sensor temperature.
- Regulator Mode** – In this mode the user selects the amount of time the floor warming system heats during a 15-minute repeating cycle. There is no temperature sensing in this mode. (see section 5 “**Operation**”)

If you want it to operate in the air sensing mode or regulator mode, you may change this as follows:

- Press the OPTIONS button and hold for 1 second.
- Press the OPTIONS button again until **SENS** shows on the display.
- Press the down or up button to toggle this to **Air** or **REGU**.
- Press the HOLD/RETURN button to return to the normal operating mode.

SENS

FL r

### Floor Limit

If you set your thermostat to operate in Air Sense Mode, the display will show the air temperature but will also monitor the floor sensor if it is connected.

To avoid possibly overheating your floor, you must set a Floor Limit temperature so it turns off the system if the floor sensor temperature exceeds this Floor Limit. Some wood and laminate floor manufacturers recommend a maximum of 82 to 84°F (27° to 28°C). Check with manufacturer. It is factory set to 99°F (37°C) and can be adjusted as follows:

- Press the OPTIONS button and hold for 1 second.
- Press the OPTIONS button again until **SET TEMP** and **FLOOR LIMIT** shows on the display with the current Floor Limit temperature.
- Press the down or up button to adjust this.
- Press the HOLD/RETURN button to return to the normal operating mode.



## Calibration

Your thermostat allows the ability to slightly adjust the display temperature. Normally this is not recommended nor required. However, in special circumstances this may be necessary, and can be done as follows:

- Press the OPTIONS button and hold for 1 second.
- Press the OPTIONS button again until **CAL** shows on the display with the current sensor temperature and the current offset value. The offset value is factory set to zero.
- Press the down or up button to adjust this.
- Press the HOLD/RETURN button to return to the normal operating mode.

CAL  
76.5  
00

## Resetting Factory Defaults

Your thermostat has the ability to reset all settings to the factory defaults. If you are certain you want to do this:

- Press the OPTIONS button and hold for 1 second.
- Press the OPTIONS button again until the software version **Soft 1.0** or similar shows on the display.
- Press the down and up buttons at the same time and hold for 1 second. **Done** and **rst** will show on the display. The thermostat will go through a startup mode and return to the normal operating mode.

Soft  
v 1.0

## 5. Operation

### Controlling the Temperature

Your thermostat has several ways to control your floor warming system.

#### Adjust the Temperature

- Press the down or up button and hold for 1 second. The setpoint temperature should be blinking.
- Press the down or up button again to adjust the temperature.
- Press the HOLD/RETURN button or wait 5 seconds and the thermostat will return to the normal operating mode, saving your adjustment.

#### Setback

You can use the Setback button to override the current setpoint temperature. This is especially useful if you have an alternate temperature you repeatedly select when you are away.

- Press the SETBACK button briefly. **SETBACK** will show on the display and its temperature.
- To cancel this Setback temperature and return to the normal temperature, press the SETBACK button briefly.

78.0  
72.0  
SETBACK  
FLOOR

#### To change the temperature stored in the SETBACK button:

- Press the SETBACK button and hold for 1 second. **SETBACK** will show on the display and its temperature should be blinking.
- Press the down or up button to adjust the temperature.
- Press the HOLD/RETURN button or wait 5 seconds and the thermostat will return to the normal operating mode, saving your adjustment.

#### Remote Control Override

If your thermostat was installed with Remote Control input from a home automation system (see section 2 “**Installation**”), this will override the thermostat when the remote control system closes its output switch or relay. **SETBACK** will show on the display and it will operate in the Setback temperature indefinitely. To cancel this, the Remote Control switch or relay must be opened.

#### Regulator Mode

If you set your thermostat to operate in the regulator mode, it will operate like a timer. You may adjust the amount of time the floor warming system heats during a 15-minute repeating cycle as follows:

- With the thermostat in the regulator mode, it will show the heating time and the current cycle time.
- Press the down or up button to adjust the heating time from 0 through 15.
  - Example: A value of 6 will cause it to heat for 6 minutes of the 15 minute cycle, and then not heat for 9 minutes of the 15 minute cycle.
  - Zero will cause it to never heat.
  - 15 will cause it to heat continuously.
- The cycle time shown at the bottom of the display is the current time in the 15-minute cycle. It repeats from 0:00 through 14:59 (min:sec).

06 HEATING  
020

## Lockout Feature

Your thermostat has the ability to lock out adjustment by other users. This may be useful in public locations. Only the on/off switch and the GFCI test button will then operate.

1. Press the down **and** up button at the same time and hold for 1 second. **LOCK** will show on the display.
2. To cancel this lockout, the down and up button must be pressed and held for 1 second. The thermostat will return to the normal operating mode.

## Test the GFCI

There is a GFCI (Ground Fault Circuit Interrupter) inside the thermostat. It is designed to help protect people from possible electrical shock if the floor warming system has been damaged.

To make sure the GFCI is operating, test it after it is installed and once each month:

1. Make sure the thermostat is **HEATING**. You may need to increase the setpoint temporarily.
2. Press the GFCI Test button on the side of the thermostat. **GFCI TRIP** should show on the display and a red light will show next to the GFCI Test button. You should also hear a click, indicating power has been removed from the floor warming system. If any of these indicators fail, turn off the thermostat and replace it. Do not continue to use.
3. To reset the GFCI, slide the On/Off switch off and back on. If the GFCI does not reset, turn the thermostat off and go to section 6 **“Troubleshooting”** for help.

## 6. Troubleshooting

Problem	Solution
Thermostat works but no heat from the system.	<ol style="list-style-type: none"> <li>1. Check wiring connections.</li> <li>2. If GFCI is tripped, reset thermostat with on/off switch.</li> <li>3. Check resistances on floor warming system. See manual for system.</li> </ol>
No display.	<ol style="list-style-type: none"> <li>1. Check wiring connections.</li> <li>2. Check circuit breaker or other protection “upstream” of thermostat.</li> <li>3. Check the 14-pin connection on the back of the Front Module. Sometimes the pins can become misaligned when connecting the Front Module to the Power Module.</li> </ol>
GFCI is tripped.	<ol style="list-style-type: none"> <li>1. Check wiring connections.</li> <li>2. Reset thermostat by switching off/on.</li> <li>3. Check resistances on floor warming system. See manual for system.</li> </ol>
Er 1 (only at startup)	Floor sensor not correct type or out of range. Check floor sensor resistance.
Er 2	Floor sensor short-circuited. Replace sensor or Reset Factory Defaults (section 4).
Er 3	Floor sensor not attached and thermostat in floor sense mode. Turn off power at circuit breaker and attach sensor. Or Reset Factory Defaults (section 4).
Er 4 or Er 5	Internal air sensor is faulty. Replace thermostat or operate in floor sense mode.
Er 6	Internal temperature overlimit. Make sure sunlight is not directed at the thermostat or other heat source in proximity. Otherwise, turn off power at breaker and contact factory.
Er 7	<ol style="list-style-type: none"> <li>1. Check the 14-pin connection on the back of the Front Module. Sometimes the pins can become misaligned when connecting the Front Module to the Power Module.</li> <li>2. “End-of-life” indication. GFCI will no longer function correctly or safely. Reset circuit breaker, otherwise replace thermostat.</li> </ol>

## 7. Specifications

Power Supply	120/240 VAC, 50/60 Hz
Maximum Load	15 amps, resistive
Maximum Power	1800 watts at 120 VAC 3600 watts at 240 VAC
GFCI	Class A (5 milliamp trip)
Display Range	32 °F to 140 °F (0 °C to 60 °C)
Setting Range	40 °F to 99 °F (4 °C to 37 °C)
Accuracy	± 0.9 °F (0.5 °C)
Storage Temp	0 °F to 120 °F (0 °C to 49 °C)
Sensor	Thermistor, 10k NTC, double-insulated
Memory	Settings retained indefinitely
ETL Listing	Control No. 3037530 Conforms to UL 873, UL 943, CSA C22.2 No. 24, and CAN/CSA C22.2 No. 144



## Limited Warranty

Watts Radiant, Inc. warrants this thermostat control and sensor (the product) to be free from defects in material and workmanship for a period of (2) years from the date of original purchase from authorized dealers. During this period, Watts Radiant, Inc. will replace the product or refund the original cost of the product at Watts Radiant's option, without charge, if the product is proven defective in normal use. Please return the thermostat to your distributor to begin the warranty process.

This limited warranty does not cover shipping costs. Nor does it cover a product subjected to misuse or accidental damage. This warranty does not cover the cost of installation, diagnosis, removal or reinstallation, or any material costs or loss of use.

This limited warranty is in lieu of all other warranties, obligations, or liabilities expressed or implied by the company. In no event shall Watts Radiant, Inc. be liable for consequential or incidental damages resulting from installation of this product. Some states or provinces do not allow limitations on how long an implied warranty lasts, or the exclusion or limitation of incidental or consequential damages, so the above exclusions or limitations may not apply to you. This warranty gives you specific legal rights and you may also have other rights that vary from state to state.

IOM-WR-SS-NonPro-EN 1125

Effective: 07/01/2011

PPLIMP08004 IND

© 2007-2011

This manual has been provided courtesy of  
My RV Works, Inc.

[www.myrvworks.com](http://www.myrvworks.com)



You can find more RV service manuals here:

[www.myrvworks.com/manuals](http://www.myrvworks.com/manuals)

Over the years of running a mobile RV repair service, having a dedicated place to access service manuals for all the different appliances and components found on RVs was something that I always had a desire to create.

I hope this resource makes your RV repairs easier, as it has mine, but please be careful and follow proper safety practices when attempting to repair your own RV.

If in doubt, please consult with a professional RV technician!



DARREN KOEPP - OWNER, MY RV WORKS, INC.

*All service manuals provided on [www.myrvworks.com](http://www.myrvworks.com) are believed to be released for distribution and/or in the public domain.*