

STAR PROPER PURGING OF LP GAS CYLINDERS

Inject 15 psig (about one atmosphere, which is 14.7 psi) pressure propane vapor into the container 6 times while exhausting the total volume of the container between loading. Please note the percentage amount of air will be reduced by just volume as shown in the following chart from the Handbook.

	% Air Remaining	% Propane Remaining
1st Purging	50	50
2nd Purging	25	75
3rd Purging	12.5	87.5
4th Purging	6.25	93.75
5th Purging	3.13	96.87
6th Purging	1.56	98.44

This manual has been provided courtesy of
My RV Works, Inc.

www.myrvworks.com



You can find more RV service manuals here:

www.myrvworks.com/manuals

Over the years of running a mobile RV repair service, having a dedicated place to access service manuals for all the different appliances and components found on RVs was something that I always had a desire to create.

I hope this resource makes your RV repairs easier, as it has mine, but please be careful and follow proper safety practices when attempting to repair your own RV.

If in doubt, please consult with a professional RV technician!



DARREN KOEPP - OWNER, MY RV WORKS, INC.

All service manuals provided on www.myrvworks.com are believed to be released for distribution and/or in the public domain.