

Cooktops

This chart will help you determine the exact specifications of the cooktop/range you have or are looking to purchase

SUBURBAN RV RANGE/COOKTOP MODEL NUMBER POSITIONS									
1	2	3	4	5	6	7	8	9	10
BRAND	TYPE	BURNER TYPE	THERMOSTAT	BURNERS	OVEN MODELS	TOP COLOR (PORCELAIN)	DOOR COLOR (PAINTED)	IGNITION	OPTIONS
S=Suburban	R=Range D=Drop-In C=Cooktop (Slide-In)	N=Conventional S=Sealed	A=Mercury Free	2=2-Burner 3=3-Burner	S=17" Oven L=22" Oven	B=Black S=Stainless P=Porcelain Stainless	B=Black S=Stainless G=Black Glass X=Stainless w/Black Glass V=Open Window Glass w/ Brush Nickel Handle U=Black w/ Brush Nickel Handle	M=Match E=Piezo S=Spark	Z=Deluxe Cooking Grate Y=Extension

This manual has been provided courtesy of
My RV Works, Inc.

www.myrvworks.com



You can find more RV service manuals here:

www.myrvworks.com/manuals

Over the years of running a mobile RV repair service, having a dedicated place to access service manuals for all the different appliances and components found on RVs was something that I always had a desire to create.

I hope this resource makes your RV repairs easier, as it has mine, but please be careful and follow proper safety practices when attempting to repair your own RV.

If in doubt, please consult with a professional RV technician!



DARREN KOEPP - OWNER, MY RV WORKS, INC.

All service manuals provided on www.myrvworks.com are believed to be released for distribution and/or in the public domain.