


# 12 V.D.C. ONLY

IF ANY OF THE ORIGINAL WIRE AS SUPPLIED WITH THE WATER HEATER MUST BE REPLACED, IT MUST BE REPLACED WITH 18 GA., 105°C WIRE OR ITS EQUIVALENT.



DISCONNECT POWER SUPPLY BEFORE SERVICING THERMOSTAT AND HI-LIMIT UNDER ACCESS COVER.  
**WIRING DIAGRAM 12 V.D.C.**

340461

si un des fils electriques livres avec le chauffe-eau doit etre remplace, utiliser a cet effet un fil 18 GA. 105°C ou equivalent.

Wiring Diagram 12 V.D.C.

This manual has been provided courtesy of  
My RV Works, Inc.

[www.myrvworks.com](http://www.myrvworks.com)



You can find more RV service manuals here:

[www.myrvworks.com/manuals](http://www.myrvworks.com/manuals)

Over the years of running a mobile RV repair service, having a dedicated place to access service manuals for all the different appliances and components found on RVs was something that I always had a desire to create.

I hope this resource makes your RV repairs easier, as it has mine, but please be careful and follow proper safety practices when attempting to repair your own RV.

If in doubt, please consult with a professional RV technician!



DARREN KOEPP - OWNER, MY RV WORKS, INC.

*All service manuals provided on [www.myrvworks.com](http://www.myrvworks.com) are believed to be released for distribution and/or in the public domain.*